

AMERICAN CAR CRAFT

18701 Old Shady Hill Rd. Spring Hill, Fl. 34610

Phone: 727 857-1151 Fax: 727 856-0273

www.americancarcraft.com

05-06 MUSTANG STAINLESS DOOR ARM TRIM PLATES

PART#MGDA508 patent pending

INSTALLATION INSTRUCTIONS

PLEASE NOTE: If you plan on installing our matching door panel inserts for best results we recommend that this door arm trim kit is installed first. However this door arm trim can be installed without our matching door panel inserts.

PARTS INCLUDED:

2-Brushed Stainless Door Arm Trim Plates

2-Packs Adhesive Promoter

2-Lengths of Chrome Molding

2-Tubes of Adhesive Promoter

1-Test Kit

Your new covers come to you with a protective liner. Do not remove liner until installation is complete.

1. Your new arm rest insert is designed to permanently stick to your door panel via 3M Super Attachment Tape and is very reliable however if this area has been treated with armor all or any silicon based treatments this installation will not work unless special chemicals and procedures are followed. Please refer to the SPECIAL INSTRUCTIONS ATTACHED.
2. Scrub the door pull area with household rubbing alcohol to prepare the surface. Once this is done use the adhesive promoter (provided) to wipe the entire area to be covered with your new arm rest plate. Allow a few seconds to dry. **You have been provided with attachment tape test strips. Use one of these to test the tack. If it seems to stick well then you can proceed with your installation. If you can not get the test tape to stick please refer back to the special preparation instruction sheet and repeat those procedures.**

3. Before permanently attaching place the arm rest plate in position to check the fit and to get acquainted with just how it installs. Once you are clear about how it sits peel the red release liner and press the panel firmly in place.
4. You have been provided with a length of chrome trim and a tube applicator of adhesive promoter. Squeeze the tube to break the fluid capsule and apply a thin swipe directly to the outer edge of the DOOR PULL AROUND the arm rest plate you just installed (see picture below for placement). NOTE: No trim is to be used for the finger hole part of the door pull.
5. Peel a small length of the red release liner from one end of the chrome trim and firmly press it directly to the plastic outer edge of the factory door pull peeling the liner as you go and making sure that the trim rests tightly against the edge of the stainless arm rest plate. Work your way to the end and cut away any excess trim.
6. Repeat process for opposite side.

