

AMERICAN CAR CRAFT

18701 Old Shady Hill Rd. Spring Hill, Fl. 34610

Phone: 727 857-1151 Fax: 727 856-0273

www.americancarcraft.com

05-06 MUSTANG RADIATOR COVER

PART#MGRS203 patent pending

INSTALLATION INSTRUCTIONS

PARTS INCLUDED:

STAINLESS RADIATOR COVER

1- REPLACEMENT PROP BAR

3-BLACK ZIP TIES

2- STAINLESS ALLEN HEAD BOLTS

2-SMALL WASHERS

2-CHROME BEZELS

1-CHROME CAP COVER

1-VELCRO ATTACHMENT COOKIE

Your new cover comes to you with a protective liner. Do not remove liner until installation is complete.

- 1. Remove the plastic factory radiator cover and factory prop bar. NOTE: The prop bar will not be reused you have been provided with a replacement prop bar. Remove all four hood stops. NOTE: Be sure to measure the height of the two outer stops before removing them! There may be two ground cables bolted at the left side of the radiator support make sure that these wires are NOT protruding to high. If they are simply push them down. Remove the front left and right fender bolts.**
- 2. You will notice the water tank overflow hose routed behind the radiator. You need to reroute this hose so that it runs inside the aluminum channel of the radiator and then zip tie the hose securely in place using the zip ties provided. Be sure not to allow the hose to ride up too high in the channel it should sit as flush in the channel as possible. You will notice that there are two small square tabs protruding up from each radiator bracket. Using a hammer tap these downward so that there won't be any possibility that they may dimple the new radiator cover.**
- 3. Carefully place the new radiator cover into position and line up the two outer holes. You have been provided with two stainless Allen head replacement**

bolts with small washers. Use these to fasten your new cover. Be sure not to over tighten these new bolts as this will distort the new cover.

- 4. You have been provided with two decorative chrome bezels. Place the two outer hood stops thru these two bezels and reinstall the hood stops and adjust them to the correct height from step one. At this time remove the protective liner and place the chrome cap cover over the windshield washer fill tube. You can do this by trimming the yellow caps finger tab off then attach using the Velcro attachment cookie provided.**

If any questions occur during installation, please contact American Car Craft at 727

857-1151.

Thank you and enjoy your new panel.

Note: Care must be taken when cleaning your panel. It is a good idea to lightly dust your panel with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.